

Read and Save These Instructions


- Installation by anyone other than a qualified contractor voids the warranty.
- Product designed for residential installation only. Commercial installation voids warranty.
- Modification or alteration of product, parts, installation instructions or local safety codes voids warranty.
- Read our full warranty policy at the end of this document.

CAUTION: Sharp edges may cause injury from cuts. Use care when handling.

WARNING: Disconnect power to furnace before installation.

Specifications

- MERV: MERV 11
- Type: Cartridge
- Weight: 58 lbs.
- Rated Air Flow: 2000 CFM
- Static Pressure Drop: .26 in w.c.
- Min. Ave. % Eff. 1.0-3.0: 61.8% (MERV 10) or 75% (MERV 11)
- Operation: Air flow from furnace through air cleaner
- Replacement Filter: GF-4551; Replace every 6-12 months
- Application: Inline
- Installation: Return Air Duct; can be adjusted for 10" or 12" duct. (See diagram below)
- Pallet Quantity: 8
- Warranty: 10 Years
- Material: Heavy 22 gauge galvanized sheet metal; riveted for sturdiness and long life
- Accommodates 3.0 or 5.0 ton electric air handler or gas furnace
- Door: Two door openings allow access from either side for installation purposes and filter replacement



Replacement Filter Size

- The Perfect Platform filter part number is GF-4551.
- Replace your filter at least once every 6 months, or more often if needed.

Door

- Affix the handle (6) to the door (only one of the two doors has holes for handles), using the two included #6 x 1/2" screws. This door is to be located on the side for which the homeowner has access for replacing the filter.

Filter Rail Spacer

- The filter rail spacer (5) is placed to the back, next to the filter track and closest to the door opening that will not be accessible. The open side of the spacer will be against the removable panel (7) at the back (inaccessible) opening.

Adjustable Center Assembly

- The center crossbar (1) is secured to the platform with the two formed flanges down. Set the crossbar in place, but do not secure it to the Perfect Platform until the intake duct adjuster (2) is also in place.
- The Perfect Platform crossbar can be adjusted to close the gap for a narrow air handler or furnace.

Duct Flanges

- The flat duct flanges (3) need to be bent up 90° and are used to secure the intake duct to the platform.
- The Perfect Platform intake duct adjuster (2) can be placed allowing for either 10" or 12" duct. The formed flange should be facing up and is used to secure the intake duct to the platform. Once the adjuster is positioned correctly four #8 x 3/8" screws are used to secure both the adjuster and crossbar to the platform at the sides. One screw is used to secure the adjuster to the crossbar in the center.

Duct Adaptors

- Two duct adaptors (4) are used if you need to reduce the intake duct to 24". The adaptors are placed where indicated, on each side of the return, and holes are drilled in the platform. Use the clearance holes on the adaptors as the locators to drill the platform holes. Do not drill holes elsewhere as this may interfere with the door. On the 2832 model the shaded area of the duct adaptor will need to be cut off to allow the intake duct to fit over the adaptor.
- IMPORTANT: Once the air handler or furnace and the duct are in place and secured, the joints must be properly sealed to prevent air leakage.

#	Description
1	Center Crossbar
2	Intake Duct Adjuster
3	Duct Flanges
4	Duct Adaptors
5	Filter Rail Spacer
6	Door Handle
7	Removable Back Panel

